

pure / merge island acrylic bath



PURE ISLAND BATH

Check that your floor is level and secure. Your Marbletrent bath does not need to be supported by a mortar bed. To adhere your bath to the floor, simply spread tile adhesive around the timber supports and allow sufficient time to cure.

1. Place bath into position and ensure that the bath is level.
The rim around the bath and the base must be fully supported.
2. Seal around bath rim with silicone(see diagram).

FAILURE TO FOLLOW OUR INSTALLATION GUIDE WILL VOID THE WARRANTY. CAREFULLY INSPECT YOUR BATH PRIOR TO INSTALLATION AS NO CLAIMS WILL BE ACCEPTED IF THE PRODUCT HAS BEEN INSTALLED.

NB. Specifications are subject to change without prior notice. We recommend that hot water applied to this product does no exceed 55°C

