

CASEY SEMI RECESSED VANITY BASIN INSTALLATION INSTRUCTIONS

1. Place template over basin counter and tape into position.
2. Check position is correct and there are no obstructions.
3. Mark around template.
4. Drill 18mm starter hole for jigsaw and cut on template line..
5. Fit tapware and waste to basin.
6. Trial fit basin in counter top to ensure correct fit.
7. Apply bead of waterproof sealant around outside edge of cut out.
Note. Basin will sit 10mm over cutout
8. With brackets provided, insert into fixing holes on each side of the basin and fix with screws
9. Clean excess sealant from around basin with a damp soft cloth.

Bench Top

Bench Face

